



1 FULL TURN OUT ON DIAL-α-GRIP MOUNTED AT B HOLE = AE A3 SETTING

TO ADJUST ARM ANGLE - LEAVE ARM PIN LOCKS TIGHT AND LOOSEN BOTH L AND R BLOCK 1/2 TURN ADJUST DIAL-α-GRIP THEN TIGHTEN WHILE PUSHING DOWN TO LOCATE.

* WE RECOMMEND RUNNING HARD SHIM OR WASHERS FOR REAR TOW ANGLE TO FREE UP BLOCK ADJUSTMENT

NOTE: IF MINOR BINDING ON REAR ARMS OCCURS WITH HIGHER TOE ANGLE SETUPS -- THEN SHIM BOTH BLOCKS .5MM TO FREE UP.